

576 Cores 1 IN 6 OUT Fiber Optic Splice Dome Generic Closure

- For FTTx Solution



Product Overview

This kind of Generic Fiber Optic Splice Dome Closure from ARTIC FIBER in China, which is splice closure is a high-capacity, field-proven solution designed for secure and reliable fiber management in demanding environments. Supporting up to 576 FO across 24 trays (24 splices per tray), this IP68/9-rated dome enclosure offers exceptional protection against water ingress, UV exposure, and temperature extremes. With six round ports and one oval port for flexible cable entry, robust mechanical sealing, and compliance with IEC standards, it is ideal for wall, pole, or direct burial installations in both new deployments and network upgrades.





Keyed Characteristics

- ✓ 6 x Round Glands;
- ✓ 1 x Oval Gland;
- ✓ 8 x 900mm Buffer tubing;
- ✓ 6 x cable ties;
- ✓ 100 x 40mm splice protectors;
- ✓ 2 x Earth Strips;
- ✓ 2 x cable retention bolts & nut;
- ✓ 1 x adhesive tape;
- ✓ 4 x silver heat protection tape;

Application

- ✓ FTTX Solution and quick maintain for FTTH Network;
- ✓ Indoor and Outdoor harsh environment.

Specification

- ✔ Working Temperature: -40 degrees centigrade~+65 degrees centigrade;
- ✓ Atmospheric Pressure: 62~106Kpa;
- ✓ Axial Tension: >1000N/lmin;
- ✓ Flatten Resistance: 2000N/100 mm(lmin);
- ✓ Insulation resistance:>2*104MQ;
- ✓ Voltage Strength: 15KVC)/lmin, no arc over or breakdown7. Temperature recycle: under -40°C∼+65°C, with 60(+5)Kpa inner pressure, in 10cycles: Inner pressure shall decrease lessthan 5 Kpa when closure turn to normal temperature;
- ✔ Durability: 25 years.

Product Parameter


Description	Details
Ports Sealing Method	Base and dome sealed with latches and O-ring system
Size: Biggest Point	278 x 162.6 x 464.5 mm
Entry Points Number	1 oval Input port
	6 Output port
Max Ttray Number	24 PCS
Tray Capacity	24 PCS
Max Closure Splice Capacity	576F (If with 24F splice, total request on 24 pcs tray)
	480F (If with 24F splice, total request on 20pcs tray)
	Dome, Base: modified PP.
Raw Material:	Clamp: Nylon +GF
	Tray: ABS
	Metal Parts: Stainless Steel



E-mail: sales@articfiber.com Mob: +86.137.1380.1094 Website: www.articfiber.com




Outer Structure



	1 Oval port, with optional rubber speac:
	1) D20: For 2pcs 18-20mm Cable
Available Cable Dia.	2) D18: For 2pcs 16-18mm Cable
	3) D16: For 2pcs 14-16mm Cable
	4) D14: For 2pcs 12-14mm Cable
	5) D12: For 2pcs 10-12mm Cable

Oval Port Details







Main Components

Name	Qty	Picture	Name	Qty	Picture	
Dome	1PC		Tray Optional	Max.24F		
				Max.12F		
Base & Inner rack & Tray holder & Latch	1PC		Vale Optinal	1		
			O-ring	1		
Cable Strengthen		10	Velcro with one X			
Member Attach Plate	1 SET	de de / s	Flake	1	(3	
Optic Joints		(theodililianslay	Ground			
Protection Tube	Max.576		feed-through	1		
Optional			Lug Optional		(A) (B)	
Nylon Tie &	Max.1Bag		4.			
Transparent PE Tube				8pcs	1 bag	
AMP Clamp Optional	1	THE RE	Shield Continuity Wire	1		
Desiccant Optional	1		Cleaning Tissue	1		
PVC Tape & Sealing		Tray Cover	Tray Cover with		A STATE OF THE STA	
Tape	Each 1 roll		Fiber Adjust Pencil	1		
Wall Mounting Kits	Standard				1	
Optional	Offered			1 11		
	with	•		上 日日		
			nung.	A		
Aerial Mounting Kits	Order as			AL A	5	
	Optional					
Pole Mounting Kits	Order as					
	Optional					






Sealing KIT for HEAT-SHRINK Sealing Closure								
	Heat-shrink Tube	1		Branch Off Clip	1			
Heat-shrink Sealing								
Kits - Oval Port	Abrasive Tape	1		Aluminum Foil	2			
Heat-shrink Sealing	Heat-shrink Tube	6		Abrasive Tape	1			
Kits - Round Port	Aluminum Foil	6		Oval port Cable Attach Plate and Metal Pin	1			

Installation Guidance

1. According to the construction needs open cable holes on the base, use abrasive trip to polish the cable inlet and outlet until smooth, then clean up the port with cleaner.



3. Strip off the outer sheath, the inner sheath of the loose shrinkable on the cable, clean the oil filling paste in the cable. Leave the fiber at the length of 1 to 1.6m, the strength steel core with the length of 30 to 50mm. Put the cable strenthen steel wire into the corresponding stud hole, adjust the distance, use paellas bend the steel wire to 90% degree but leave 1cm long, then cut oof the spare steel wire. Tighten the screws on the stud.



2. Clean up the cable head which need to be spliced. Frst put the cables through the round and oval ports mechanical or heat-shrink sealing kits.



4. Put the bare fibers through the transparent PE tube, use PVC tape wrap the end of the PE tube and cable.





5. For mechanical closure, fix the cable in the oval port as below picture. Tighten the screws slightly, then put the oval port sealing kits into the oval port. (Do not tighten the screws too hard to cause deformation of the rubber here. Same as for the round mechnical sealing kits.)





E-mail: sales@articfiber.com Mob: +86.137.1380.1094 Website: www.articfiber.com

6. For heat-shrink, fix the cable on the attach plate. then using the metal pin to fix the plate on the closure.



7. Fix the transparent bare fiber protective tube into the tube fixing holder, and store the optic fibers in the storage block. (The spiral tube is also availble)




9. Fiber routing from the storage basket to the splice tray.



When splicing, pick up the steel wire on the splice tray, then stuck on the slot of the route to support up to splice tray.

11. Until the fibers close to the tray entry, then quide the fibers into the tray.







10. Using the fiber adjust pencil to guide the optic fibers into the grooves of the tray holder.



The fiber routing from the storage basket to the splice tray as shown in the figure. Splice tray must be in accordance with the groove routing. The splice tray fix on which line of the groove, the fiber must from same line routing. As the fiber routing groove is too deep, a fiber guiding pin can be used to move the fiber into or out of the groove.





12. Splicing of fibers in the splice tray.

Pull gently on the fibers in the tray and make sure that the fibers are well general coiled in the contained in the routing block and tray holder. Store the fibers temporally on the tray. The first lap fiber general coiled in the outermost side of the splice tray. The other fibers shall be coiled with the diameter not less than 80mm. Put the Splic protective tube on the fiber joints and fusion them together oderly. The fiber protective tube shall be put together with the fiber into the splice cassette. (First fix the fiber protective tube to the tray slots, and then enlarge the fiber Circle to proper size.)









13. Repeat the steps, operate other splice tray from top to the bottom until all the fiber fusion iscompleted and confirmed, then put on the tray lid and storage block cover, then bind the Velcro strip.





14. (OPTIONAL)

Closure can hold max. 16 pes adapter with SC adapter sized fixing holes. And 1pc 1*16 splitter isavailable

